BUILDING SIDE SETBACK PLANE

Defines the planes within which, except for permitted encroachments, all portions of a building must remain. The planes shall be measured beginning at 10' directly above the established grade at the side lot lines and run at a 45° angle toward the interior of the lot until they reach the maximum building height permitted on the lot.